




# BASC33

## Assembly View & Parts List



Key #	Description	Part No.
1	Front Cover Assembly	GJ324-01
2	Spinnerhead Assembly	EY310-03
3	E-Clip	EY034-01
4	Drag Washer Kit - includes	EY4108-01
4A	Drag Washer	
4B	Keyed Drag Washer	
4C	Spring Washer	
5	Spool Assembly	EY321-01
6	Drag Cam Plate	EY027-01
	Handle Assembly Kit - includes	GJ4318-01
7	Handle Assembly	
10	Crank Rod Assembly	

Key #	Description	Part No.
8	Body Assembly	N / A
9	Bushing	EY026-01
10	Crank Rod Assembly	EY367-01
11	M2.5 X 10 Screw	GJ149-02
12	Back Cover Assembly	EY323-01
13	Battery, Lithium CR20-32	GJ157-01
14	Battery Cover Kit - includes	GJ4154-01
	Module Cover	
	Module Gasket	
11	M2.5 X 10 Screw	

